

# SDR-1000 CAT COMMAND DICTIONARY

## GENERAL INFORMATION

A CAT command consists of a prefix, a parameter list, and a terminator. Commands fall into one of three categories: Get (read) commands that request status information from the transceiver; Set (write) commands that change transceiver status; and Answer (response) commands that return information requested in a Get command or error codes. A correctly executed Set command does not return an Answer command.

The terminator for all CAT commands is the semicolon (;). CAT commands are not case sensitive. Get and Set commands must contain the correct number of parameter characters as shown in the accompanying tables. Most Get commands are simply the prefix followed by a termination, but there are special cases where a Get command will require parameters.

### Kenwood Compatible Commands

<b>AG Sets or reads the AF Gain thumbwheel control</b>										
<b>Get</b>	AG	P1	;							
<b>Set</b>	AG	P1	P2	P2	P2	;				
<b>Answer</b>	AG	P1	P2	P2	P2	;				
<b>Notes</b>	P1 = 0 for main transceiver, 1 for future sub receiver. P2 = 000 to 255 (scaled 0 to 100 in software). An Set value of 127 = 50 on the AF Gain thumbwheel. Also see ZZAG.									

<b>BD Moves the transceiver down one band</b>										
<b>Get</b>										
<b>Set</b>	BD	;								
<b>Answer</b>										
<b>Notes</b>	BD is write-only									

<b>BU Moves the transceiver up one band</b>										
<b>Get</b>										
<b>Set</b>	BU	;								
<b>Answer</b>										
<b>Notes</b>	BU is write-only									

<b>FA Sets or reads VFO A frequency</b>										
<b>Get</b>	FA	;								
<b>Set</b>	FA	P1	P1	P1	P1	P1	P1	P1	P1	P1
		P1	P1	;						
<b>Answer</b>	FA	P1	P1	P1	P1	P1	P1	P1	P1	P1
		P1	P1	;						
<b>Notes</b>	P1 = frequency in Hz (11 digits). Blank digits must be 0. Example: 14,320.150 = 00014320150.									

<b>FB Sets or reads VFO B frequency</b>										
<b>Get</b>	FB	;								
<b>Set</b>	FB	P1	P1	P1	P1	P1	P1	P1	P1	P1
		P1	P1	;						
<b>Answer</b>	FB	P1	P1	P1	P1	P1	P1	P1	P1	P1
		P1	P1	;						
<b>Notes</b>	P1 = frequency in Hz (11 digits). Blank digits must be 0. Example: 14,320.150 = 00014320150.									

<b>FR Sets or reads the transceiver receive VFO</b>										
<b>Get</b>	FR	;								
<b>Set</b>	FR	P1	;							
<b>Answer</b>	FR	P1	;							
<b>Notes</b>	Added for third-party compatibility. P1 = 0 since the SDR-1000 VFO A is always the receive VFO.									

<b>FT Sets or reads the transceiver transmit VFO</b>										
<b>Get</b>	FT	;								
<b>Set</b>	FT	P1	;							
<b>Answer</b>	FT	P1	;							
<b>Notes</b>	P1 = 0 for VFO A, 1 for VFO B.									

<b>FW Sets or reads the DSP receive filter width</b>										
<b>Get</b>	FW	;								
<b>Set</b>	FW	P1	P1	P1	P1	;				
<b>Answer</b>	FW	P1	P1	P1	P1	;				
<b>Notes</b>	FW only accepts SDR-1000 filter widths. See ZZFI for values.									

<b>GT Sets or reads the AGC time constant thumbwheel control</b>										
<b>Get</b>	GT	;								
<b>Set</b>	GT	P1	P1	P1	;					
<b>Answer</b>	GT	P1	P1	P1	;					
<b>Notes</b>	P1: Fixed = 000, Long = 001, Slow = 002, Med = 003, 004 = Fast.									

<b>ID Reads the transceiver ID number</b>										
<b>Get</b>	ID	;								
<b>Set</b>										
<b>Answer</b>	ID	P1	P1	P1	;					
<b>Notes</b>	P1 defaults to 019 (TS-2000). The SDR-1000 id code (900) may be selected remotely using ZZID. ID is read-only.									

<b>IF Reads the transceiver status</b>										
<b>Get</b>	IF	;								
<b>Set</b>										
<b>Answer</b>	IF	P1	P1	P1	P1	P1	P1	P1	P1	P1
	P1	P1	P2	P2	P2	P2	P3	P3	P3	P3
	P3	P3	P4	P5	P6	P7	P7	P8	P9	P10
	P11	P12	P13	P14	P14	P15	;			
<b>Notes</b>	<p>P1 (11 characters) VFO A frequency in Hz. Same as FA;  P2 (4 characters) Frequency step size expressed in powers of 10 (see ZZST).  P3 (6 characters) RIT/XIT frequency (+nnnnn or -nnnnn).  P4 (1 character) RIT status. 0 = off, 1 = on.  P5 (1 character) XIT status. 0 = off, 1 = on.  P6 (1 character) Channel bank number. Not used, defaulted to 0.  P7 (2 characters) Channel bank number. Not used, defaulted to 00.  P8 (1 character) MOX button status. 0 = off, 1 = on (transmitting).  P9 (1 character) Operating mode. See MD for settings.  P10 (1 character) VFO Split status. Same as FR (always 0).  P11 (1 character) Scan status. Not implemented, defaulted to 0.  P12 (1 character) VFO Split status. Same as FT.  P13 (1 character) CTCSS tone. Not used, defaulted to 0.  P14 (2 characters) More tone controls. Not used, defaulted to 00.  P15 (1 character) Shift status. Not used, defaulted to 0.</p> <p>P9 will return a space if a non-Kenwood mode is selected on the SDR-1000.</p>									

<b>MD Sets or reads the transceiver operating mode</b>										
<b>Get</b>	MD	;								
<b>Set</b>	MD	P1	;							
<b>Answer</b>	MD	P1	;							
<b>Notes</b>	P1 values: 1 = LSB 2 = USB 3 = CWU 4 = FMN 5 = AM 6 = RTTY 7 = CWL									

<b>MG Sets or reads the Microphone Gain thumbwheel control</b>										
<b>Get</b>	MG	;								
<b>Set</b>	MG	P1	P1	P1	;					
<b>Answer</b>	MG	P1	P1	P1	;					
<b>Notes</b>	P1 = 000 to 100.									

<b>MO Sets or reads the Monitor (MON) status</b>										
<b>Get</b>	MO	;								
<b>Set</b>	MO	P1	;							
<b>Answer</b>	MO	P1	;							
<b>Notes</b>	P1 = 0 for on, 1 for off.									

<b>NB Sets or reads the Noise Blanker 1 (NB1) status</b>										
<b>Get</b>	NB	;								
<b>Set</b>	NB	P1	;							
<b>Answer</b>	NB	P1	;							
<b>Notes</b>	P1 = 0 for on, 1 for off.									

<b>NT Sets or reads the Automatic Notch Filter (ANF) status</b>										
<b>Get</b>	NT	;								
<b>Set</b>	NT	P1	;							
<b>Answer</b>	NT	P1	;							
<b>Notes</b>	P1 = 0 for on, 1 for off.									

<b>PC Sets or reads the PA Power (PWR) status</b>										
<b>Get</b>	PC	;								
<b>Set</b>	PC	P1	P1	P1	;					
<b>Answer</b>	PC	P1	P1	P1	;					
<b>Notes</b>	P1 = 000 to 100.									

<b>PR Sets or reads the Speech Compressor (COMP) status</b>										
<b>Get</b>	PR	;								
<b>Set</b>	PR	P1	;							
<b>Answer</b>	PR	P1	;							
<b>Notes</b>	P1 = 0 for on, 1 for off.									

<b>PS Sets or reads the Power Button status</b>										
<b>Get</b>	PS	;								
<b>Set</b>	PS	P1	;							
<b>Answer</b>	PS	P1	;							
<b>Notes</b>	P1: 0 = Standby, 1 = On.									

<b>QI Sets the Quick Save memory (QS)</b>										
<b>Get</b>										
<b>Set</b>	QI	;								
<b>Answer</b>										
<b>Notes</b>	QI is write-only.									

<b>RC Clears the RIT frequency (RIT[0])</b>										
<b>Get</b>										
<b>Set</b>	RC	;								
<b>Answer</b>										
<b>Notes</b>	RC is write-only.									

<b>RT Sets or reads the RIT button status</b>										
<b>Get</b>	RT	;								
<b>Set</b>	RT	P1	;							
<b>Answer</b>	RT	P1	;							
<b>Notes</b>	P1 = 0 for on, 1 for off.									

<b>RX Sets the transceiver to Receive mode (MOX off)</b>										
<b>Get</b>										
<b>Set</b>	RX	;								
<b>Answer</b>										
<b>Notes</b>	RX is write-only.									

<b>SH Sets or reads the variable DSP Filter high frequency</b>									
<b>Get</b>	SH	;							
<b>Set</b>	SH	P1	P1	;					
<b>Answer</b>	SH	P1	P1	;					
<b>Notes</b>	SSB Modes (USB, LSB, CWU and CWL) in Hz 00 = 1400 01 = 1600 02 = 1800 03 = 2000 04 = 2200 05 = 2400 06 = 2600 07 = 2800 08 = 3000 09 = 3400 10 = 4000 11 = 5000  DSB Modes (AM, DSB, FMN, DRM, SAM) 00 = 2500 01 = 3000 02 = 4000 03 = 5000  SH has no effect in RTTY, PSK, or SPEC.								

<b>SL Sets or reads the variable DSP filter low frequency</b>										
<b>Get</b>	SL	;								
<b>Set</b>	SL	P1	P1	;						
<b>Answer</b>	SL	P1	P1	;						
<b>Notes</b>	SSB Modes (USB, LSB, CWU and CWL) in Hz 00 = 0 01 = 50 02 = 100 03 = 200 04 = 300 05 = 400 06 = 500 07 = 600 08 = 700 09 = 800 10 = 900 11 = 1000  DSB Modes (AM, DSB, FMN, DRM, SAM) 00 = 0 01 = 100 02 = 200 03 = 500  SL has no effect in RTTY, PSK, or SPEC.									

<b>SM Reads the S-Meter</b>										
<b>Get</b>	SM	;								
<b>Set</b>										
<b>Answer</b>	SM	P1	P2	P2	P2	P2	;			
<b>Notes</b>	P1 = 0 for main transceiver. P2 = 0000 to 0030 where 0015 = S9. Current code needs improvement for readings above S9. SM is read-only.									

<b>SQ Sets or reads the Squelch (SQL) thumbwheel control</b>										
<b>Get</b>	SQ	P1	;							
<b>Set</b>	SQ	P1	P2	P2	P2	;				
<b>Answer</b>	SQ	P1	P2	P2	P2	;				
<b>Notes</b>	P1 = 0 for main transceiver. P2 = 000 to 255 (scaled in software to 0 – 160, SQ0127; = 80 on the control.									

<b>TX Sets the transceiver to Transmit mode (MOX on)</b>										
<b>Get</b>										
<b>Set</b>	TX	;								
<b>Answer</b>										
<b>Notes</b>	TX is write-only. Not totally compatible with Kenwood but is modified to maintain compatibility with third-party software.									

<b>XT Sets or reads the XIT status</b>										
<b>Get</b>	XT	;								
<b>Set</b>	XT	P1	;							
<b>Answer</b>	XT	P1	;							
<b>Notes</b>	P1 = 0 for on, 1 for off.									



## SDR-1000 Custom Commands

<b>ZZAG Sets or reads the SDR-1000 Audio Gain control</b>										
<b>Get</b>	ZZAG	;								
<b>Set</b>	ZZAG	P1	P1	P1	;					
<b>Answer</b>	ZZAG	P1	P1	P1	;					
<b>Notes</b>	P1 = 000 to 100.									

<b>ZZBG Sets or reads the Band Group (HF/VHF)</b>										
<b>Get</b>	ZZBG	;								
<b>Set</b>	ZZBG	P1	;							
<b>Answer</b>	ZZBG	P1	;							
<b>Notes</b>	P1 = 0 for HF, 1 for VHF.									

<b>ZZBI Sets or reads the Binaural (BIN) status</b>										
<b>Get</b>	ZZBI	;								
<b>Set</b>	ZZBI	P1	;							
<b>Answer</b>	ZZBI	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									

<b>ZZBS Sets or reads the Band Switch</b>										
<b>Get</b>	ZZBS	;								
<b>Set</b>	ZZBS	P1	P1	P1	;					
<b>Answer</b>	ZZBS	P1	P1	P1	;					
<b>Notes</b>	P1 values: 160, 080, 060, 040, 030, 020, 017, 015, 012, 010, 006, 002 (when 2 meter transverter is installed), 888 (GEN), and 999 (WWV).									

<b>ZZCL Sets or reads the CW Pitch (Setup   DSP)</b>										
<b>Get</b>	ZZCL	;								
<b>Set</b>	ZZCL	P1	P1	P1	P1	;				
<b>Answer</b>	ZZCL	P1	P1	P1	P1	;				
<b>Notes</b>	P1 = 0200 to 1200.									

<b>ZZCP Sets or reads the Compander (CMP) button status</b>										
<b>Get</b>	ZZCP	;								
<b>Set</b>	ZZCP	P1	;							
<b>Answer</b>	ZZCP	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									

<b>ZZCS Sets or reads the CW Speed</b>										
<b>Get</b>	ZZCS;									
<b>Set</b>	ZZCS	P1	P1	;						
<b>Answer</b>	ZZCS	P1	P1	;						
<b>Notes</b>	P1 = 01 to 60									

<b>ZZCU Reads the CPU Usage</b>										
<b>Get</b>	ZZCU	;								
<b>Set</b>										
<b>Answer</b>	ZZCU	P1	P1	P1	P1	P1	P1	;		
<b>Notes</b>	P1 = 000.00 to 100.00									

<b>ZZDA Sets or reads the Display Average (AVG) status</b>										
<b>Get</b>	ZZDA	;								
<b>Set</b>	ZZDA	P1	;							
<b>Answer</b>	ZZDA	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									

<b>ZZDM Sets or reads the Display Mode</b>										
<b>Get</b>	ZZDM	;								
<b>Set</b>	ZZDM	P1	;							
<b>Answer</b>	ZZDM	P1	;							
<b>Notes</b>	P1 values: 0 = Spectrum 1 = Panadapter 2 = Scope 3 = Phase 4 = Phase2 5 = Waterfall 6 = Histogram 7 = Off									

<b>ZZFI Sets or reads the current DSP receive filter</b>										
<b>Get</b>	ZZFI	;								
<b>Set</b>	ZZFI	P1	P1	;						
<b>Answer</b>	ZZFI	P1	P1	;						
<b>Notes</b>	P1 values: 00 = 6.0K 01 = 4.0K 02 = 2.6K 03 = 2.1K 04 = 1.0K 05 = 500 06 = 250 07 = 100 08 = 50 09 = 25 10 = VAR1 11 = VAR2									

<b>ZZGT Sets or reads the AGC thumbwheel control</b>										
<b>Get</b>	ZZGT	;								
<b>Set</b>	ZZGT	P1	;							
<b>Answer</b>	ZZGT	P1	;							
<b>Notes</b>	P1 values: 0 = Fixed 1 = Long 2 = Slow 3 = Med 4 = Fast 5 = Custom									

<b>ZZID Sets the transceiver identification to SDR-1000</b>										
<b>Get</b>										
<b>Set</b>	ZZID	;								
<b>Answer</b>										
<b>Notes</b>	ZZID is used to remotely force the transceiver id to 900 (SDR-1000).									

<b>ZZIF Reads the SDR-1000 status</b>										
<b>Get</b>	ZZIF	P1	;							
<b>Set</b>										
<b>Answer</b>	ZZIF	P1	P2	P2	P2	P2	P2	P2	P2	P2
	P2	P2	P2	P3	P3	P3	P3	P4	P4	P4
	P4	P4	P4	P5	P6	P7	P8	P8	P9	P10
	P10	P11	P12	P13	P14	P15	P15	P16	;	
<b>Notes</b>	P1 = 0 P2 (11 characters) VFO A frequency in Hz. Same as FA; P3 (4 characters) Frequency step size expressed in powers of 10 (see ZZST). P4 (6 characters) RIT/XIT frequency (+nnnnn or -nnnnn). P5 (1 character) RIT status. 0 = off, 1 = on. P6 (1 character) XIT status. 0 = off, 1 = on. P7 (1 character) Channel bank number. Not used, defaulted to 0. P8 (2 characters) Channel bank number. Not used, defaulted to 00. P9 (1 character) MOX button status. 0 = off, 1 = on (transmitting). P10 (2 character) Operating mode. See ZZMD for settings. P11 (1 character) VFO Split status. Same as FR (always 0). P12 (1 character) Scan status. Not implemented, defaulted to 0. P13 (1 character) VFO Split status. Same as ZZSP. P14 (1 character) CTCSS tone. Not used, defaulted to 0. P15 (2 characters) More tone controls. Not used, defaulted to 00. P16 (1 character) Shift status. Not used, defaulted to 0.									

<b>ZZIS Sets or reads the variable filter width slider</b>										
<b>Get</b>	ZZIS	;								
<b>Set</b>	ZZIS	P1	P1	P1	P1	P1	;			
<b>Answer</b>	ZZIS	P1	P1	P1	P1	P1	;			
<b>Notes</b>	P1 = 00000 to 10000.									

<b>ZZIT Sets or reads the variable filter shift slider</b>										
<b>Get</b>	ZZIT	;								
<b>Set</b>	ZZIT	P1	P2	P2	P2	P2	;			
<b>Answer</b>	ZZIT	P1	P2	P2	P2	P2	;			
<b>Notes</b>	P1 = "+" or "-" P2 = 0000 to 1000 (-1000 to +1000)									

<b>ZZIU Resets the variable filter shift slider</b>										
<b>Get</b>										
<b>Set</b>	ZZIU	;								
<b>Answer</b>							;			
<b>Notes</b>	Write only									

<b>ZZMA Sets or reads the Mute (MUT) status</b>										
<b>Get</b>	ZZMA	;								
<b>Set</b>	ZZMA	P1	;							
<b>Answer</b>	ZZMA	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									

<b>ZZMD Sets or reads the Operating Mode</b>										
<b>Get</b>	ZZMD	;								
<b>Set</b>	ZZMD	P1	P1	;						
<b>Answer</b>	ZZMD	P1	P1	;						
<b>Notes</b>	P1 values: 00 = LSB 01 = USB 02 = DSB 03 = CWL 04 = CWU 05 = FMN 06 = AM 07 = DIGU 08 = SPEC 09 = DIGL 10 = SAM 11 = DRM									

<b>ZZMG Reserved (Mic pregain deleted in 1.3.13)</b>										
<b>Get</b>	ZZMG	;								
<b>Set</b>	ZZMG									
<b>Answer</b>	ZZMG									
<b>Notes</b>										

<b>ZZMR Sets or reads the RX Meter mode</b>										
<b>Get</b>	ZZMR	;								
<b>Set</b>	ZZMR	P1	;							
<b>Answer</b>	ZZMR	P1	;							
<b>Notes</b>	P1 Values: 0 = Signal Strength 1 = Signal Average 2 = ADC L 3 = ADC R 4 = Off									

<b>ZZMT Sets or reads the TX Meter mode</b>										
<b>Get</b>	ZZMT	;								
<b>Set</b>	ZZMT	P1	;							
<b>Answer</b>	ZZMT	P1	;							
<b>Notes</b>	P1 Values: 0 = ALC 1 = Forward Power 2 = Peak Power 3 = Reverse Power 4 = SWR (Console must be in TUN mode to set TX meter to SWR) 5 = Off									

<b>ZZNB Sets or reads the Noise Blanker 2 (NB2) status</b>										
<b>Get</b>	ZZNB	;								
<b>Set</b>	ZZNB	P1	;							
<b>Answer</b>	ZZNB	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									

<b>ZZNL Sets or reads the Noise Blanker 1 threshold (Setup DSP tab)</b>										
<b>Get</b>	ZZNL	;								
<b>Set</b>	ZZNL	P1	P1	P1	;					
<b>Answer</b>	ZZNL	P1	P1	P1	;					
<b>Notes</b>	P1 = 001 to 200.									

<b>ZZNM Sets or reads the Noise Blanker 2 threshold (Setup DSP tab)</b>										
<b>Get</b>	ZZNM	;								
<b>Set</b>	ZZNM	P1	P1	P1	P1	;				
<b>Answer</b>	ZZNM	P1	P1	P1	P1	;				
<b>Notes</b>	P1 = 0001 to 1000.									

<b>ZZNR Sets or reads the Noise Reduction (NR) status</b>										
<b>Get</b>	ZZNR	;								
<b>Set</b>	ZZNR	P1	;							
<b>Answer</b>	ZZNR	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									

<b>ZZPA Sets or reads the Preamplifier (Preamp) setting</b>										
<b>Get</b>	ZZPA	;								
<b>Set</b>	ZZPA	P1	;							
<b>Answer</b>	ZZPA	P1	;							
<b>Notes</b>	P1 values; 0 = Off 1 = Low 2 = Med 3 = High									

<b>ZZPL Sets or reads the Speech Compressor threshold (Setup Transmit tab)</b>										
<b>Get</b>	ZZPL	;								
<b>Set</b>	ZZPL	P1	P1	;						
<b>Answer</b>	ZZPL	P1	P1	;						
<b>Notes</b>	P1 = 00 to 20.									

<b>ZZQM Reads the Quick Save Memory value</b>										
<b>Get</b>	ZZQM	;								
<b>Set</b>										
<b>Answer</b>	ZZQM	P1	P1	P1	P1	P1	P1	P1	P1	P1
		P1	P1	;						
<b>Notes</b>	P1 = frequency in Hz (11 digits). Example: 14,320.150 = 00014320150.									

<b>ZZQR Restores the Quick Save Memory (QR)</b>										
<b>Get</b>										
<b>Set</b>	ZZQR	;								
<b>Answer</b>										
<b>Notes</b>	ZZQR is write-only									

<b>ZZRF Sets or reads the RIT frequency</b>										
<b>Get</b>	ZZRF;									
<b>Set</b>	ZZRF	P1	P2	P2	P2	P2				
<b>Answer</b>	ZZRF	P1	P2	P2	P2	P2				
<b>Notes</b>	P1 = polarity (+ or -) P2 = frequency in Hz.									

<b>ZZRM Reads the SDR-1000 Console Multimeter</b>										
<b>Get</b>	ZZRM	P1	;							
<b>Set</b>										
<b>Answer</b>	ZZRM	P1	P2	P2	P2	P2	P2	P2	P2	P2
	P2	P2	P2	P2	P2	P2	P2	P2	P2	P2
	P2	P2	;							
<b>Notes</b>	P1 Values: 0 = Signal Strength 1 = Average Strength 2 = ADC_L 3 = ADC_R 4 = ALC 5 = Forward Power 6 = Peak Power 7 = Reverse Power 8 = SWR P2 is padded left with spaces.  ZZRM is read-only.									

<b>ZZSF Sets the variable filter width and center (KD5TFD filters)</b>										
<b>Get</b>										
<b>Set</b>	ZZSF	P1	P1	P1	P1	P2	P2	P2	P2	
<b>Answer</b>										
<b>Notes</b>	P1 = center frequency in Hz. P2 = width in Hz. ZZSF is write-only.									

<b>ZZSM Reads the S-Meter</b>										
<b>Get</b>	ZZSM	P1	;							
<b>Set</b>										
<b>Answer</b>	ZZSM	P1	P2	P2	P2	;				
<b>Notes</b>	P1 = 0 P2 = 000 to 260 Each increment of ZZSM is approximately equal to 0.5 dBm.									

<b>ZZSO Sets or reads the Squelch on/off status</b>										
<b>Get</b>	ZZSO	;								
<b>Set</b>	ZZSO	P1	;							
<b>Answer</b>	ZZSO	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									



<b>ZZSP Sets or reads the VFO Split (SPLT) status</b>										
<b>Get</b>	ZZSP	;								
<b>Set</b>	ZZSP	P1	;							
<b>Answer</b>	ZZSP	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									

<b>ZZSQ Sets or reads the SDR-1000 Squelch control</b>										
<b>Get</b>	ZZSQ	;								
<b>Set</b>	ZZSQ	P1	P1	P1	;					
<b>Answer</b>	ZZSQ	P1	P1	P1	;					
<b>Notes</b>	P1 = 000 to 160.									

<b>ZZST Reads the frequency step size</b>										
<b>Get</b>	ZZST	;								
<b>Set</b>										
<b>Answer</b>	ZZST	P1	P1	P1	P1	;				
<b>Notes</b>	P1 values are expressed in BCD powers of 10: 0000 = 10e0 = 1 Hz 0001 = 10e1 = 10 Hz 0010 = 10e2 = 100 Hz 0011 = 10e3 = 1 kHz 0100 = 10e4 = 10 kHz 0101 = 10e5 = 100 kHz 0110 = 10e6 = 1 mHz 0111 = 10e7 = 10 mHz ZZST is read-only.									

<b>ZZTH Sets or reads the TX Filter High setting</b>										
<b>Get</b>	ZZTH	;								
<b>Set</b>	ZZTH	P1	P1	P1	P1	P1	;			
<b>Answer</b>	ZZTH	P1	P1	P1	P1	P1	;			
<b>Notes</b>	P1 = 00500 to 20000. ZZTH does not change the Setup form TX Filter High setting, the SDR-1000 will default to that setting on power up.									

<b>ZZTL Sets or reads the TX Filter Low setting</b>										
<b>Get</b>	ZZTL	;								
<b>Set</b>	ZZTL	P1	P1	P1	P1	;				
<b>Answer</b>	ZZTL	P1	P1	P1	P1	;				
<b>Notes</b>	P1 = 0000 to 2000. ZZTL does not change the Setup form TX Filter Low setting, the SDR-1000 will default to that setting on power up.									

<b>ZZTU Sets or reads the Tune (TUN) status</b>										
<b>Get</b>	ZZTU	;								
<b>Set</b>	ZZTU	P1	;							
<b>Answer</b>	ZZTU	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on. Console power must be on for TUN to function.									

<b>ZZVL Sets or reads the VFO Lock status</b>										
<b>Get</b>	ZZVL	;								
<b>Set</b>	ZZVL	P1	;							
<b>Answer</b>	ZZVL	P1	;							
<b>Notes</b>	P1 = 0 for off, 1 for on.									

<b>ZZVN Reads the PowerSDR software version number</b>										
<b>Get</b>	ZZVN	;								
<b>Set</b>										
<b>Answer</b>	ZZVN	P1	;							
<b>Notes</b>	Returns ZZVN001.3.14.0; ten total characters including decimal points.									

<b>ZZVS Sets the VFO Swap status</b>										
<b>Get</b>										
<b>Set</b>	ZZVS	P1	;							
<b>Answer</b>										
<b>Notes</b>	P1 values: 0 = A>B 1 = A<B 2 = A<>B ZZVS is write-only.									

<b>ZZXC Clears the XIT frequency (XIT[0])</b>										
<b>Get</b>										
<b>Set</b>	ZZXC	;								
<b>Answer</b>										
<b>Notes</b>	ZZXC is write-only.									

<b>ZZXF Sets or reads the XIT frequency</b>										
<b>Get</b>	ZZXF;									
<b>Set</b>	ZZXF	P1	P2	P2	P2	P2	;			
<b>Answer</b>	ZZXF	P1	P2	P2	P2	P2	;			
<b>Notes</b>	P1 = polarity (+ or -) P2 = frequency in Hz.									

January 3, 2006 Revisions:

Corrected typo in MD.

Changed ZZMD to reflect DIGU and DIGL.

Added ZZTH and ZZTL commands.